


# Whirlpool LTE6234DT4 02 - DRYER FRONT PANEL AND DOOR PARTS

## DRYER FRONT PANEL AND DOOR PARTS

For Models: LTE6234DQ4, LTE6234DT4  
(Designer White) (Biscuit)



2

8180760

Whirlpool [Residential Whirlpool LTE6234DT4 Washer/Dryer Parts](#) Parts Diagram 02 - DRYER FRONT PANEL AND DOOR PARTS

[Click on the part number to view part](#)

| Item | Original Part Number    | Replaced By             | Status | Part Description    |
|------|-------------------------|-------------------------|--------|---------------------|
| 1    | <a href="#">3389249</a> |                         |        | Nut, Inner Door     |
| 2    | 3391901                 | <a href="#">3391902</a> |        | Switch, Door        |
| 3    | <a href="#">98234</a>   |                         |        | Clip, U-Bend        |
| 4    | 3392547                 | <a href="#">279718</a>  |        | Panel               |
| "    | 3977780                 | <a href="#">279938</a>  |        | Panel               |
| 5    | <a href="#">3390735</a> |                         |        | Seal, Door          |
| 6    | 3392563                 | <a href="#">280083</a>  |        | Door-Rear           |
| 7    | <a href="#">3387872</a> |                         |        | Door, Front         |
| "    | <a href="#">3387877</a> |                         |        | Door, Front         |
| 8    | <a href="#">3388229</a> |                         |        | Retainer, Toe Panel |
| 9    | <a href="#">3387242</a> |                         |        | Seal, Front Panel   |
| 11   | 696144                  | <a href="#">279570</a>  |        | Latch               |
| 12   | 697773                  | <a href="#">3395530</a> |        | Screw               |
| 13   | 3393008                 | <a href="#">308685</a>  |        | Side Trim )         |
| 14   | 3392538                 | <a href="#">279570</a>  |        | Latch               |
| 15   | <a href="#">3389522</a> |                         |        | Handle, Door        |

|    |                         |                        |                        |
|----|-------------------------|------------------------|------------------------|
| "  | <a href="#">3389528</a> |                        | Handle, Door           |
| 16 | <a href="#">3390902</a> |                        | Clip, Door Hinge       |
| 17 | <a href="#">3388958</a> |                        | Panel, Toe             |
| "  | <a href="#">3388963</a> |                        | Panel, Toe             |
| 19 | 342055                  | <a href="#">488627</a> | Screw                  |
| 20 | <a href="#">3389247</a> |                        | Hinge And Pin Assembly |
| 23 | <a href="#">694091</a>  |                        | Trim, Side Right Hand  |

