


Whirlpool LTG5243DQ5 16 - 3402856 BURNER ASSEMBLY, OPTIONAL PARTS (NOT INCLUDED)

3402856 BURNER ASSEMBLY

For Models: LTG5243DQ5, LTG5243DTS
(Designer White) (Biscuit)

USE WITH TYPE 1 - NATURAL, TYPE 2 - MIXED, TYPE 3 - MANUFACTURED
AND TYPE 4 - LIQUEFIED PROPANE AND BUTANE GASES



8180782

19

Whirlpool [Residential Whirlpool LTG5243DQ5 Washer/Dryer Parts](#) Parts Diagram 16 - 3402856 BURNER ASSEMBLY, OPTIONAL PARTS (NOT INCLUDED).
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	3402856	W10492503		Burner-Gas
2	697408		Not Available	Base, Burner
3	3401777	279888		Valve-Assembly
4	234822			Orifice
"	347743			Orifice
5	3401849			Harness
6	694539			Coil, 60 Hz
7	694540			Coil, 60 Hz
8	694424			Leak, Limiter
9	694421			Screw, Bracket Mounting
10	694538			Bracket, Shunt
11	694422			Spring, Regulator
12	239822	W10295523		Plug, Pipe
13	694423			Screw, Regulator Adjustment
15	3392268		Not Available	Burner

16	3387057		Screw, 10-16 X 1/2 Orifice, Burner
17	686590	279311	Ignitor
18	3393909		Screw, 8-32 X 7/8
20	697409		Bracket, Sensor
21	338906		Radiant, Sensor
22	3406051		Elbow Union Assembly
23	3388638	W10110397	Pipe
24	3391118		Supply Line
25	233076		Nut, Compression
26	3393767		Pipe, Tail
"	BLANK	Not Available	Following Parts Not Illustrated
"	49573	49573A	LP Gas Con
"	72017		Paint, Touch-Up
"	4392899		Paint, Touch-Up
"	350938		Paint, Pressurized Spray B
"	350930		Paint, Pressurized Spray B
"	4392901		Paint, Pressurized Spray
"	799344		Paint, Touch-Up)
"	4392900		Paint, Bulk)
"	BLANK	Not Available	ACCESSORY PARTS
"	692790		Kit, Grounding Plug, Dryer Side Panel
"	3977784		Plug, Dryer Side Panel
"	BLANK	Not Available	OIL
"	350572		Oil
"	BLANK	Not Available	LUBRICANT
"	285208		Lubricant
"	BLANK	Not Available	SEALER
"	285195		Sealer Sealer, Gasket

