


Whirlpool LTG5243DT5 02 - DRYER FRONT PANEL AND DOOR PARTS

DRYER FRONT PANEL AND DOOR PARTS

For Models: LTG5243DQ5, LTG5243DT5
(Designer White) (Biscuit)



2

8180782

Whirlpool [Residential Whirlpool LTG5243DT5 Washer/Dryer Parts](#) Parts Diagram 02 - DRYER FRONT PANEL AND DOOR PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	3406108			Door Switch
2	697773	3395530		Screw
4	692619	285314		Panel
"	3978587	285836		Panel
5	3390734			Seal, Door
6	695656	280077		Door
7	348205			Door, Front
"	3978598			Door, Front
9	8066123	279264		Air Channel Box
10	685203	279220		Clip
11	696144	279570		Latch
12	3390663	681414		Screw, 10AB X 1/2
13	343641	681414		Screw, 10AB X 1/2
14	3389441			Door Catch Assembly
15	686711			Handle, Door
"	3978592			Handle, Door

