


# Whirlpool LTG5243DT8 02 - DRYER FRONT PANEL AND DOOR PARTS

## DRYER FRONT PANEL AND DOOR PARTS

For Models: LTG5243DQ8, LTG5243DT8  
(Designer White) (Biscuit)



2

W10259009

Whirlpool [Residential Whirlpool LTG5243DT8 Washer/Dryer Parts](#) Parts Diagram 02 - DRYER FRONT PANEL AND DOOR PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">3406108</a>			Door Switch
2	697773	<a href="#">3395530</a>		Screw
3	<a href="#">348023</a>			Hinge And Pin Assembly
4	692619	<a href="#">285314</a>		Panel
"	3978587	<a href="#">285836</a>		Panel
5	<a href="#">3390734</a>			Seal, Door
6	695656	<a href="#">280077</a>		Door
7	<a href="#">348205</a>			Door, Front
"	<a href="#">3978598</a>			Door, Front
8	<a href="#">694091</a>			Trim, Side Right Hand
9	8066123	<a href="#">279264</a>		Air Channel Box
10	685203	<a href="#">279220</a>		Clip
11	696144	<a href="#">279570</a>		Latch
12	3390663	<a href="#">681414</a>		Screw, 10AB X 1/2
13	343641	<a href="#">681414</a>		Screw, 10AB X 1/2
14	<a href="#">3389441</a>			Door Catch Assembly

