


Whirlpool LTG5243DT8 06 - WASHER TOP AND LID PARTS

WASHER TOP AND LID PARTS

For Models: LTG5243DQ8, LTG5243DT8
(Designer White) (Biscuit)



8

W10259009

Whirlpool Residential Whirlpool LTG5243DT8 Washer/Dryer Parts Parts Diagram 06 - WASHER TOP AND LID PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	3398848			Lid
"	3398849			Lid
2	9724509			Bumper, Lid
3	91770			Hinge, Lid
4	W10119872	W10119828		Screw, Lid Hinge Mounting
5	692985			Clip, Spring
6	384693			Top
"	3978593			Top
7	21258			Bearing, Lid Hinge
8	3356311			Screw And Washer, Lid Switch Shield
9	358684			Strike, Lid Switch
10	3400030	33001178		Back, Tumbler
11	8533959	680762		Nut
12	3355806			Switch, Lid
13	90016			Clip, Pressure Switch Hose