


Whirlpool LTG5243DT8 07 - WASHER CABINET PARTS

WASHER CABINET PARTS

For Models: LTG5243DQ8, LTG5243DT8
(Designer White) (Biscuit)



W10259009

9

Whirlpool [Residential Whirlpool LTG5243DT8 Washer/Dryer Parts](#) Parts Diagram 07 - WASHER CABINET PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	356746			Clip, Condenser
2	343641	681414		Screw, 10AB X 1/2
3	9740848			Screw, Mixing Valve Mounting
4	3350013			Foam
5	3952163	285805		Valve-Inlet
6	370451	596669		Clamp, Manifold
7	692699			Hose, Water Inlet
8	696013			Cabinet
"	3978594			Cabinet
9	3390046			Protector, Edge
10	696710			Hose, Drain
11	692400			Nut, Push-In
12	660975			Plug, Top To Cabinet
13	8557915			Connector, Hose
14	370445	285655		Clamp, Hose
15	356471			Cap, Siphon Break

16	356363		Siphon Break
17	272861	Not Available	Clamp, Hose
18	696394		Hose, Water Inlet
19	367594		Foot, Front
20	358594		Foot, Rear
21	692628		Panel, Front
"	3978596		Panel, Front
22	3394083		Clip, Front Panel
23	358652		Link, Leveling
24	359364		Clip, Leveling Mechanism
25	98234		Clip, U-Bend
26	345670		Lock, Top

the laundry company[®]

the laundry company[®]

the laundry company[®]