


Whirlpool LTG6234DQ2 05 - DRYER SUPPORT AND WASHER HARNESS PARTS

DRYER SUPPORT AND WASHER HARNESS PARTS

For Models: LTG6234DQ2, LTG6234DT2
(Designer White) (Biscuit)



8180162

7

Whirlpool [Residential Whirlpool LTG6234DQ2 Washer/Dryer Parts](#) Parts Diagram 05 - DRYER SUPPORT AND WASHER HARNESS PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	8299848			Harness - Washer 1a 3350130 Plug, 3 Way 1B 3347243 Connector, 5 Way 1C 352089 Block, Disconnect - Timer 1D 3350211 Receptacle
2	3388851			Channel Assembly
"	BLANK		Not Available	(Left Hand Side)
3	3388850			Channel Assembly
"	BLANK		Not Available	(Right Hand Side)
4	3390609			Shield, Harness
5	8545438			Hose, Pressure Switch
6	8281256			Clip, Harness
7	343641	681414		Screw, 10AB X 1/2
13	3400300	Y015627		Screw- Hex
14	3393930	4342911		Nut
15	3392232			Shield, Front

16	3390336	Shield, Thermostat
18	3391249	Cable Tie, Push Mount
19	3354925	Block, Connector
20	3360056	Connector
23	94614	Terminal
24	63523	Harness, Protector

