


Whirlpool LTG6234DQ2 14 - MISCELLANEOUS PARTS AND OPTIONAL PARTS NOT INCLUDED

MISCELLANEOUS PARTS

For Models: LTG6234DQ2, LTG6234DT2
(Designer White) (Biscuit)



Whirlpool [Residential Whirlpool LTG6234DQ2 Washer/Dryer Parts](#) Parts Diagram 14 - MISCELLANEOUS PARTS AND OPTIONAL PARTS NOT INCLUDED
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	3356714	285609		Parts-Misc
2	16123			Washer Inlet-Hose Miscellaneous Parts Must be Ordered Separately.
3	356138			Clamp, Hose
5	3357331			Clamp, Drain
"	72017			Paint, Touch-Up
"	4392899			Paint, Touch-Up
"	350938			Paint, Pressurized Spray B
"	350930			Paint, Pressurized Spray B
"	4392901			Paint, Pressurized Spray
"	799344			Paint, Touch-Up)
"	4392900			Paint, Bulk)
"	350572			Oil
"	285208			Lubricant

