


Whirlpool LTG6234DQ3 01 - WASHER/DRYER CONTROL PANEL PARTS



9-05 Litho in U.S.A. (LT)

1

Part No. 8180809

Whirlpool [Residential Whirlpool LTG6234DQ3 Washer/Dryer Parts](#) Parts Diagram 01 - WASHER/DRYER CONTROL PANEL PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	8572777		Not Available	Installation Instructions
"	3406880		Not Available	Installation Instructions (English)
"	8542752		Not Available	Sheet, Cycle Feature
"	8546674		Not Available	Wiring Diagram
"	8576493		Not Available	Energy Guide
2	3390688			Spacer- Foam Pad
3	8528583			Bracket, Control
4	3948357			Timer, Washer
5	3396689			Panel, Control
"	3406828			Panel, Control
6	3957845			Dial,
"	3957846			Dial,
7	3957825			Knob, Timer
"	3957826			Knob, Timer
8	3957796			Knob, Control

"	3957797		Knob, Push-To-Start
9	688805		Clip, Spring Knob
11	3957750		Knob, Timer
"	3957751		Knob, Timer
12	3400064		Screw, Timer Mounting
13	8546175	W10311356	Switch-WL
14	3405157		Switch, Temperature
15	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
16	3404233		Switch, Push-To-Start
18	694419		Mini-Buzzer
19	3976569		Timer, Dryer
20	3393810		Jumper Wire
21	3389453		Bracket, Hinge
22	3389456		End Cap
"	3389462		End Cap
23	3398983		Harness - Dryer
"	2154470		Receptacle,
"	3395683		Receptacle, Multi-Terminal
24	3390604		Clamp, Harness
25	3390422	W10134185	Clip, Harness
26	3401674		Wire, Jumper
27	3401684		Jumper, Wire
29	3389464		End Cap
"	3389470		End Cap

the laundry company[®]

the laundry company[®]