


# Whirlpool LTG6234DQ3 05 - DRYER SUPPORT AND WASHER HARNESS PARTS

## DRYER SUPPORT AND WASHER HARNESS PARTS

For Models: LTG6234DQ3, LTG6234DT3  
(Designer White) (Biscuit)



8180809

7

Whirlpool [Residential Whirlpool LTG6234DQ3 Washer/Dryer Parts](#) Parts Diagram 05 - DRYER SUPPORT AND WASHER HARNESS PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">8299848</a>			Harness - Washer 1a 3350130 Plug, 3 Way 1B 3347243 Connector, 5 Way 1C 352089 Block, Disconnect - Timer 1D 3350211 Receptacle
"	<a href="#">3350130</a>			Plug, Terminal
"	<a href="#">3347243</a>			Block, Disconnect
"	<a href="#">352089</a>			Timer, Block Disconnect
"	3350211		Not Available	Receptacle, 3 Way
"	<a href="#">62505</a>			Block, Disconnect
2	<a href="#">3388851</a>			Channel Assembly
3	<a href="#">3388850</a>			Channel Assembly
4	<a href="#">3390609</a>			Shield, Harness
5	<a href="#">8545438</a>			Hose, Pressure Switch
6	<a href="#">8281256</a>			Clip, Harness
7	343641	<a href="#">681414</a>		Screw, 10AB X 1/2

13	3400300	<a href="#">Y015627</a>	Screw- Hex
14	3393930	<a href="#">4342911</a>	Nut
15	<a href="#">3392232</a>		Shield, Front
16	<a href="#">3390336</a>		Shield, Thermostat
18	<a href="#">3391249</a>		Cable Tie, Push Mount
19	<a href="#">3354925</a>		Block, Connector
20	<a href="#">3360056</a>		Connector
23	94613	<a href="#">596797</a>	Terminal
"	<a href="#">94614</a>		Terminal
24	<a href="#">63523</a>		Harness, Protector

