


Whirlpool LTG6234DQ5 03 - DRYER CABINET AND MOTOR PARTS



Whirlpool [Residential Whirlpool LTG6234DQ5 Washer/Dryer Parts](#) Parts Diagram 03 - DRYER CABINET AND MOTOR PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	660658			Clamp, Motor Mounting 343481 685441
2	8538266	279811		Motor-Drve
3	3398948			Wire, Jumper
4	3394881	279782		Switch-Lid
5	3388858			Bracket, Motor
6	3389847	280039		Panel
7	343641	681414		Screw, 10AB X 1/2
8	3387673	279814		Cover
9	8533971	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
10	3389264			Panel, Side
"	3389269			Panel, Side)
"	3389256			Panel, Side
"	3389261			Panel, Side
11	3390631			Screw, 10-16 X 3/8

12	3389431		Bumper, Lid Stop
"	3389436		Bumper, Lid Stop
13	697438		Clip
14	3394081		Wire, Broken Belt Switch
15	3389231		Clip, Front Panel
16	98234		Clip, U-Bend
17	3391639		Bracket, Bulkhead
18	690997		Washer, Thrust
19	690997		Washer, Thrust
20	3387610	661570	Belt
21	3391087	279811	Motor-Drive
22	3389332	3389331	Pulley, Idler
24	3391668		Base, Dryer
25	3387374		Spring, Idler
26	3389683		Cove, Transition Panel
27	3389272		Panel, Transition
"	3389277		Panel, Transition
28	3389537		Top, Dryer
30	3389682		Space-Toe Panel User-Interface
32	694018	W10239314	Cord, Power
35	98129		Screw, 6-20 X 1 1/16
38	3389420		Retainer-Idler 1/4-20 X 1/16
39	3388672	279640	Pulley-Idr
43	3394743	Not Available	Pin, Roll
44	692400		Nut, Push-In
47	693304		Screw And Washer
49	3390722		Shield, Console To Drum
51	8066120		Lever, Door Switch

