


# Whirlpool LTG6234DT3 03 - DRYER CABINET AND MOTOR PARTS



Whirlpool [Residential Whirlpool LTG6234DT3 Washer/Dryer Parts](#) Parts Diagram 03 - DRYER CABINET AND MOTOR PARTS

[Click on the part number to view part](#)

| Item | Original Part Number    | Replaced By            | Status | Part Description                           |
|------|-------------------------|------------------------|--------|--|
| 1    | <a href="#">660658</a>  |                        |        | Clamp, Motor Mounting<br>343481 685441     |
| 2    | 8538266                 | <a href="#">279811</a> |        | Motor-Drve                                 |
| 3    | <a href="#">3398948</a> |                        |        | Wire, Jumper                               |
| 4    | 3394881                 | <a href="#">279782</a> |        | Switch-Lid                                 |
| 5    | <a href="#">3388858</a> |                        |        | Bracket, Motor                             |
| 6    | 3389847                 | <a href="#">280039</a> |        | Panel                                      |
| 7    | 343641                  | <a href="#">681414</a> |        | Screw, 10AB X 1/2                          |
| 8    | 3387673                 | <a href="#">279814</a> |        | Cover                                      |
| 9    | 8533971                 | <a href="#">90767</a>  |        | Screw, 8A X 3/8 HeX Washer<br>Head Tapping |
| 10   | <a href="#">3389264</a> |                        |        | Panel, Side                                |
| "    | <a href="#">3389269</a> |                        |        | Panel, Side )                              |
| "    | <a href="#">3389256</a> |                        |        | Panel, Side                                |
| "    | <a href="#">3389261</a> |                        |        | Panel, Side                                |
| 11   | <a href="#">3390631</a> |                        |        | Screw, 10-16 X 3/8                         |

|    |                         |                           |                                |
|----|-------------------------|---------------------------|--------------------------------|
| 12 | <a href="#">3389431</a> |                           | Bumper, Lid Stop               |
| "  | <a href="#">3389436</a> |                           | Bumper, Lid Stop               |
| 13 | <a href="#">697438</a>  |                           | Clip                           |
| 14 | <a href="#">3394081</a> |                           | Wire, Broken Belt Switch       |
| 15 | <a href="#">3389231</a> |                           | Clip, Front Panel              |
| 16 | <a href="#">98234</a>   |                           | Clip, U-Bend                   |
| 17 | <a href="#">3391639</a> |                           | Bracket, Bulkhead              |
| 18 | <a href="#">233520</a>  |                           | Washer, Thrust                 |
| 19 | <a href="#">690997</a>  |                           | Washer, Thrust                 |
| 20 | 3387610                 | <a href="#">661570</a>    | Belt                           |
| 21 | 3391087                 | <a href="#">279811</a>    | Motor-Drive                    |
| 22 | 3389332                 | <a href="#">3389331</a>   | Pulley, Idler                  |
| 24 | <a href="#">3391668</a> |                           | Base, Dryer                    |
| 25 | <a href="#">3387374</a> |                           | Spring, Idler                  |
| 26 | <a href="#">3389683</a> |                           | Cove, Transition Panel         |
| 27 | <a href="#">3389272</a> |                           | Panel, Transition              |
| "  | <a href="#">3389277</a> |                           | Panel, Transition              |
| 28 | <a href="#">3389537</a> |                           | Top, Dryer                     |
| 30 | <a href="#">3389682</a> |                           | Space-Toe Panel User-Interface |
| 32 | 694018                  | <a href="#">W10239314</a> | Cord, Power                    |
| 35 | <a href="#">98129</a>   |                           | Screw, 6-20 X 1 1/16           |
| 38 | <a href="#">3389420</a> |                           | Retainer-Idler 1/4-20 X 1/16   |
| 39 | 3388672                 | <a href="#">279640</a>    | Pulley-Idr                     |
| 43 | 3394743                 | Not Available             | Pin, Roll                      |
| 44 | <a href="#">692400</a>  |                           | Nut, Push-In                   |
| 47 | <a href="#">693304</a>  |                           | Screw And Washer               |
| 49 | <a href="#">3390722</a> |                           | Shield, Console To Drum        |
| 51 | <a href="#">8066120</a> |                           | Lever, Door Switch             |

