


Whirlpool LTG6234DT3 05 - DRYER SUPPORT AND WASHER HARNESS PARTS

DRYER SUPPORT AND WASHER HARNESS PARTS

For Models: LTG6234DQ3, LTG6234DT3
(Designer White) (Biscuit)



8180809

7

Whirlpool Residential Whirlpool LTG6234DT3 Washer/Dryer Parts Diagram 05 - DRYER SUPPORT AND WASHER HARNESS PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	8299848			Harness - Washer 1a 3350130 Plug, 3 Way 1B 3347243 Connector, 5 Way 1C 352089 Block, Disconnect - Timer 1D 3350211 Receptacle
"	3350130			Plug, Terminal
"	3347243			Block, Disconnect
"	352089			Timer, Block Disconnect
"	3350211		Not Available	Receptacle, 3 Way
"	62505			Block, Disconnect
2	3388851			Channel Assembly
3	3388850			Channel Assembly
4	3390609			Shield, Harness
5	8545438			Hose, Pressure Switch
6	8281256			Clip, Harness
7	343641	681414		Screw, 10AB X 1/2

13	3400300	Y015627	Screw- Hex
14	3393930	4342911	Nut
15	3392232		Shield, Front
16	3390336		Shield, Thermostat
18	3391249		Cable Tie, Push Mount
19	3354925		Block, Connector
20	3360056		Connector
23	94613	596797	Terminal
"	94614		Terminal
24	63523		Harness, Protector

