


Whirlpool LTG6234DT3 15 - 3402855 BURNER ASSEMBLY, OPTIONAL PARTS (NOT INCLUDED)

3402855 BURNER ASSEMBLY

For Models: LTG6234DQ3, LTG6234DT3
(Designer White) (Biscuit)



8180809

21

Whirlpool [Residential Whirlpool LTG6234DT3 Washer/Dryer Parts](#) Parts Diagram 15 - 3402855 BURNER ASSEMBLY, OPTIONAL PARTS (NOT INCLUDED).
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	3401795	279726		Burner-Gas
2	3391699			Base, Burner
3	3401776	279889		Valve-Assembly
4	3394360		Not Available	ORIFICE, NATURAL GAS
"	15422		Not Available	ORIFICE, BURNER (TYPE 4) (BUTANE)
6	694539			Coil, 60 Hz
7	694540			Coil, 60 Hz
9	694421			Screw, Bracket Mounting
10	694538			Bracket, Shunt
12	239822	W10295523		Plug, Pipe
15	3392268		Not Available	Burner
16	3387057			Screw, 10-16 X 1/2 Orifice, Burner
17	686590	279311		Ignitor

18	3393909		Screw, 8-32 X 7/8
20	697409		Bracket, Sensor
21	338906		Radiant, Sensor
22	3406051		Elbow Union Assembly
23	3391845	W10110398	Pipe, Supply
24	3391118		Supply Line
25	233076		Nut, Compression
26	3393767		Pipe, Tail
"	BLANK	Not Available	Following Parts Not Illustrated
"	3392235	3392235A	LP Gas Con
"	72017		Paint, Touch-Up
"	4392899		Paint, Touch-Up
"	350938		Paint, Pressurized Spray B
"	350930		Paint, Pressurized Spray B
"	4392901		Paint, Pressurized Spray
"	799344		Paint, Touch-Up)
"	4392900		Paint, Bulk)
"	BLANK	Not Available	OIL
"	350572		Oil
"	BLANK	Not Available	LUBRICANT
"	285208		Lubricant
"	BLANK	Not Available	SEALER
"	285195		Sealer Sealer, Gasket
"	BLANK	Not Available	ACCESSORIES
"	3391335	279823	Side Exhaust Extension Kit

tools
the laundry company®

tools
the laundry company®