


MISCELLANEOUS PARTS

For Models: LXR7244PQ1, LXR7244PT1
(Designer White) (Biscuit)



Whirlpool Residential Whirlpool LXR7244PQ1 Washer Parts Parts Diagram 10 - MISCELLANEOUS PARTS, OPTIONAL PARTS

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	3957361			Miscellaneous Parts Bag
2	3976300	16123		Washer Inlet-Hose Miscellaneous Parts Must be Ordered Separately.
3	3359452			Nut, Lock
4	389102	W10001130		Foot, Leveling
"	72017			Paint, Touch-Up
"	4392899			Paint, Touch-Up
"	350938			Paint, Pressurized Spray B
"	350930			Paint, Pressurized Spray B
"	4392901			Paint, Pressurized Spray
"	799344			Paint, Touch-Up)
"	4392900			Paint, Bulk)
"	BLANK		Not Available	OIL
"	350572			Oil
"	BLANK		Not Available	LUBRICANT

"	285208		Lubricant
"	BLANK	Not Available	SEALER
"	285195		Sealer Sealer, Gasket
"	BLANK	Not Available	ACCESSORY PARTS
"	63580		Dispenser, Fabric Softener
"	367031		Water System Parts
"	285320		Water System Parts

