


# Whirlpool RAB2121PW2 01 - TOP AND CABINET PARTS



## TOP AND CABINET PARTS

For Model: RAB2121PW2  
(White)

AUTOMATIC  
WASHER



11-05 Litho in U.S.A. (dtd)

1

Part No. 8180995

Whirlpool [Residential Whirlpool RAB2121PW2 Washer Parts](#) Parts Diagram 01 - TOP AND CABINET PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	3957165		Not Available	Installation Instructions
"	3955872		Not Available	Use & Care Guide
"	3955913		Not Available	Feature Sheet
"	8546684		Not Available	Wiring Diagram
"	3957471		Not Available	Energy Guide
2	<a href="#">8541621</a>			Top
4	<a href="#">357213</a>			Nut, Push-In
5	<a href="#">63128</a>			Cabinet
6	<a href="#">62780</a>			Clip, Top And Cabinet And Rear Panel
7	3357011	<a href="#">308685</a>		Side Trim )
8	<a href="#">3351614</a>			Screw, Gearcase Cover Mounting
11	<a href="#">8318084</a>			Switch, Lid
13	3351355	<a href="#">W10119828</a>		Screw, Lid Hinge Mounting
15	<a href="#">8318088</a>			Hinge, Lid
16	<a href="#">54583</a>			Hinge, Lid

17	<a href="#">19119</a>		Bumper, Lid Hinge
18	<a href="#">21258</a>		Bearing, Lid Hinge
19	8542382	<a href="#">W10193857</a>	Lid
22	<a href="#">9724509</a>		Bumper, Lid
28	<a href="#">3390631</a>		Screw, 10-16 X 3/8

