


Whirlpool RAS7133PQ0 01 - TOP AND CABINET PARTS



04-04 Litho in U.S.A. (drd)

1

Part No. 8180323

Whirlpool Residential Whirlpool RAS7133PQ0 Washer Parts Parts Diagram 01 - TOP AND CABINET PARTS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	LIT3956025		Not Available	Literature Parts (Installation Instructions)
"	LIT3955913		Not Available	Feature Sheet
"	LIT3955872			Literature Parts
"	LIT3956324		Not Available	Literature Parts (Energy Guide)
"	LIT8542380		Not Available	Literature Parts (Wiring Diagram)
2	8318068			Top
3	62750			Spacer, Cabinet To Top (4)
4	357213			Nut, Push-In
5	63424			Cabinet
6	62780			Clip, Top And Cabinet And Rear Panel
7	3357011	308685		Side Trim)
8	3351614			Screw, Gearcase Cover Mounting
11	8318084			Switch, Lid
13	3351355	W10119828		Screw, Lid Hinge Mounting

15	8318088		Hinge, Lid
16	54583		Hinge, Lid
17	19119		Bumper, Lid Hinge
18	21258		Bearing, Lid Hinge
19	8542382	W1019385Z	Lid
22	9724509		Bumper, Lid
28	3390631		Screw, 10-16 X 3/8

