


Whirlpool RAS7133PQ1 01 - TOP AND CABINET PARTS



5-05 Litho in U.S.A. (drd)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

1

Part No. 8180662

Whirlpool Residential Whirlpool RAS7133PQ1 Washer Parts Parts Diagram 01 - TOP AND CABINET PARTS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	3957165		Not Available	Installation Instructions
"	3955913		Not Available	Feature Sheet
"	3955872		Not Available	Use & Care Guide
"	3957356		Not Available	Energy Guide
"	8542380		Not Available	Wiring Diagram
2	8318068			Top
3	62750			Spacer, Cabinet To Top (4)
4	357213			Nut, Push-In
5	63424			Cabinet
6	62780			Clip, Top And Cabinet And Rear Panel
7	3357011	308685		Side Trim)
8	3351614			Screw, Gearcase Cover Mounting
11	8318084			Switch, Lid
13	3351355	W10119828		Screw, Lid Hinge Mounting
15	8318088			Hinge, Lid

16	54583		Hinge, Lid
17	19119		Bumper, Lid Hinge
18	21258		Bearing, Lid Hinge
19	8542382	W1019385Z	Lid
22	9724509		Bumper, Lid
28	3390631		Screw, 10-16 X 3/8

