


Whirlpool RAS8244LQ0 02 - CONTROLS AND REAR PANEL PARTS



Whirlpool Residential Whirlpool RAS8244LQ0 Washer Parts Parts Diagram 02 - CONTROLS AND REAR PANEL PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	3976300	16123		Washer Inlet-Hose Miscellaneous Parts Must be Ordered Separately.
2	9740848			Screw, Mixing Valve Mounting
3	3949374	89503		Hose-Inlet
"	3949375	89503		Hose-Inlet
4	3357027			Nozzle, Hose Drain
5	8318255	8568314		Strap, Console
6	3357978			Panel, Rear
7	62747			Pad, Rear Panel
8	3951609	285664		Hose
"	661577	285666		Hose
"	3357090	285702		Hose
9	3953146			Timer, Control
10	8055003			Clip, Harness And Pressure Switch
11	3351614			Screw, Gearcase Cover Mounting

12	3366847	W10337780	Switch-WL
13	3948608		Bracket, Control
14	661661	285800	Cord-Power
15	3952821	285777	Relief-Str
16	8274437	279960	Endcap
17	3400073		Screw, Ground
18	3952164	285805	Valve-Inlet
19	3976395		Restraint, Hose
20	303294	3367669	Protector, Edge
21	370451	596669	Clamp, Manifold
22	3357328		Hose, Vacuum Break
23	371503	596669	Clamp, Manifold
24	387606	3360977	Break-Vac
25	3976286		Shield, Capacitor
26	8317940	W10358149	Drain Hose Assembly
27	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
28	3366912	356138	Clamp, Hose
30	3363366	616099	Clamp
31	8317496	285655	Clamp, Hose
32	3951449	285871	Hose
33	8318201	8318046	Clip, Capacitor
34	661606	8572717	Capacitor, Motor Start
35	661614		Switch, Water Temperature
36	3400818		Screw, Timer Mounting
39	3955681		Panel, Console
44	8274390	3957821	Knob, Timer
45	8274395	3957844	Dial
47	8274378		Knob, Control
49	388326		Screw, 8-18 X 1.25
50	62863	3390631	Screw, 10-16 X 3/8
51	8274434	279960	Endcap
56	3366913	3357331	Clamp, Drain
59	3348424	8539874	Shield, Suds
60	3955021		Harness, Wiring

