


Whirlpool RAX4232PQ1 02 - CONTROL AND REAR PANEL PARTS



8180625

3

Whirlpool [Residential Whirlpool RAX4232PQ1 Washer Parts](#) Parts Diagram 02 - CONTROL AND REAR PANEL PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	3976300	16123		Washer Inlet-Hose Miscellaneous Parts Must be Ordered Separately.
2	3400073			Screw, Ground
3	8571377	89503		Hose-Inlet
"	8571378	89503		Hose-Inlet
4	8541672	8577378		U-Bend, Drain Hose
5	8568314			Strap, Console
6	8318015			Panel, Rear
7	62747			Pad, Rear Panel
8	8559373	W10096921		Drain Hose Assembly
9	3954563			Timer, Control
10	3351614			Screw, Gearcase Cover Mounting
11	90767			Screw, 8A X 3/8 HeX Washer Head Tapping
12	3366849	W10339228		Switch-WL
13	3948608			Bracket, Control

14	661661	285800	Cord-Power
15	3952821	285777	Relief-Str
16	8274437	279960	Endcap
17	9740848		Screw, Mixing Valve Mounting
18	3955673	285805	Valve-Inlet
19	8541668		Clamp, Hose
20	8318046		Clip, Capacitor
21	301958	596669	Clamp, Manifold
22	8541607	3357328	Hose, Vacuum Break
23	370450	596669	Clamp, Manifold
24	3347034		Break, Vacuum
25	303294	3367669	Protector, Edge
26	8519200		Support, Rear Panel
27	8541667		Clamp, Hose
28	661606	8572717	Capacitor, Motor Start
29	8317975		Restraint, Harness
30	3363366	616099	Clamp
31	8317496	285655	Clamp, Hose
32	3951449	285871	Hose
33	8055003		Clip, Harness And Pressure Switch
34	8559320		Restraint, Hose
36	3400818		Screw, Timer Mounting
37	8541669		Bucket, Drain Hose
"	BLANK	Not Available	(Left Half)
38	8541658		Bucket, Drain Hose
"	BLANK	Not Available	(Right Half)
39	3956971		Panel, Console
44	3956905		Knob, Timer
45	8557457	Not Available	Dial, Timer
46	8536939		Clip, Knob
47	8557459		Knob, Control
49	388326		Screw, 8-18 X 1.25
50	62863	3390631	Screw, 10-16 X 3/8
51	8274434	279960	Endcap
55	3347868	W10339879	Tie, Cable
60	3957024		Harness, Wiring

