


Whirlpool RAX7244KQ2 01 - TOP AND CABINET PARTS



TOP AND CABINET PARTS

For Model: RAX7244KQ2
(Designer White)

AUTOMATIC
WASHER



1-04 Litho In U.S.A. (drd)

1

Part No. 8180191

Whirlpool Residential Whirlpool RAX7244KQ2 Washer Parts Parts Diagram 01 - TOP AND CABINET PARTS

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	LIT3956025		Not Available	Literature Parts (Installation Instructions)
"	LIT3955913		Not Available	Feature Sheet
"	LIT3955872			Literature Parts
"	LIT3956350		Not Available	Literature Parts (Energy Guide)
"	LIT8541941		Not Available	Literature Parts (Wiring Diagram)
2	8318064			Top
3	62750			Spacer, Cabinet To Top (4)
4	357213			Nut, Push-In
5	63424			Cabinet
6	62780			Clip, Top And Cabinet And Rear Panel
7	3362952			Dispenser, Bleach
8	3351614			Screw, Gearcase Cover Mounting
9	3357011	308685		Side Trim)
11	8318084			Switch, Lid

13	3351355	W10119828	Screw, Lid Hinge Mounting
15	8318088		Hinge, Lid
16	54583		Hinge, Lid
17	19119		Bumper, Lid Hinge
18	21258		Bearing, Lid Hinge
19	8542382	W10193857	Lid
22	9724509		Bumper, Lid
28	3390631		Screw, 10-16 X 3/8

