


Whirlpool RAX7244PQ1 10 - MISCELLANEOUS PARTS, OPTIONAL PARTS (NOT INCLUDED)

MISCELLANEOUS PARTS

For Model: RAX7244PQ1
(Designer White)



Whirlpool [Residential Whirlpool RAX7244PQ1 Washer Parts](#) Parts Diagram 10 - MISCELLANEOUS PARTS, OPTIONAL PARTS (NOT INCLUDED)

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	3957361			Miscellaneous Parts Bag
2	3976300	16123		Washer Inlet-Hose Miscellaneous Parts Must be Ordered Separately.
3	3359452			Nut, Lock
4	389102	W10001130		Foot, Leveling
	72017			Paint, Touch-Up
"	350938			Paint, Pressurized Spray B
"	350930			Paint, Pressurized Spray B
"	799344			Paint, Touch-Up)
"	BLANK		Not Available	OIL
"	350572			Oil
"	BLANK		Not Available	LUBRICANT
"	285208			Lubricant
"	BLANK		Not Available	SEALER

"	285195	Sealer Sealer, Gasket
"	BLANK	Not Available
"	63580	ACCESSORY PARTS
"	367031	Dispenser, Fabric Softener
"	285320	Water System Parts
"	285320	Water System Parts

