


Whirlpool REX2614LQ0 02 - CABINET PARTS



8180076

3

Whirlpool Residential Whirlpool REX2614LQ0 Dryer Parts Parts Diagram 02 - CABINET PARTS

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	342055	488627		Screw
2	3393008	308685		Side Trim)
4	343641	681414		Screw, 10AB X 1/2
5	3396795			Cover, Terminal Block
7	3396807	280040		Panel-Rear
8	694091			Trim, Side Right Hand
10	3406102			Door Switch Assembly
11	697773	3395530		Screw
12	3392100	49621		Feet-Leveling
"	279810			Foot-Optional
13	8530603	8533643		Cabinet
14	98234			Clip, U-Bend
15	690363	18776		Lock, Front Top
16	693197	280062		Panel
17	685203	279220		Clip
18	3389441			Door Catch Assembly

19	348023		Hinge And Pin Assembly
20	3394083		Clip, Front Panel
21	696144	279570	Latch
22	695656	280077	Door
23	348205		Door, Front
24	686711		Handle, Door
25	8066123	279264	Air Channel Box
26	279393		Terminal Block Screw Kit
27	3397659		Block, Terminal
28	238088	8066217	Hinge, Top
29	3394332	691366	Idler And Pulley Assembly
30	8066065	341241	Belt
31	348780		Base, Motor
32	3400500		Bolt, 3405245 5/16-18 X 3/4
33	3394341	W10299847	Pulley-Motor
34	8538262	279827	Motor-Drve
35	660658		Clamp, Motor Mounting 343481 685441
36	3404162		Clamp, Motor
37	3390734		Seal, Door
38	697776	4331106	Screw, No.10-32 X 7/16
39	693995		Screw, Hex Head
40	279318		Terminal Tinned And Brass Panel

