


Whirlpool REX3614PW0 02 - CABINET PARTS



8180426

3

Whirlpool [Residential Whirlpool REX3614PW0 Dryer Parts](#) Parts Diagram 02 - CABINET PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	8541400			Bracket, Cabinet
2	3393008	308685		Side Trim)
4	343641	681414		Screw, 10AB X 1/2
5	3396795			Cover, Terminal Block
7	3396807	280040		Panel-Rear
8	342055	488627		Screw
9	3404413			Plug, Hinge Hole
10	3406104	3406105		Door Switch Assembly
11	697773	3395530		Screw
13	693995			Screw, Hex Head
16	3392100	49621		Feet-Leveling
18	8530603	8533643		Cabinet
19	98234			Clip, U-Bend
20	690363	18776		Lock, Front Top
21	3403571	279844		Panel
23	685203	279220		Clip

24	690081	279570	Latch
28	3405514	W10362431	Hinge And Pin Assembly
29	3394083		Clip, Front Panel
33	696144	279570	Latch
35	3403371		Door, Inner
36	3403361		Door Front
37	3405184		Handle, Door
38	8066124	279264	Air Channel Box
40	279393		Terminal Block Screw Kit
41	3397659		Block, Terminal
51	238088	8066217	Hinge, Top
53	691366		Idler And Pulley Assembly
56	8066065	341241	Belt
57	348780		Base, Motor
58	3400500		Bolt, 3405245 5/16-18 X 3/4
59	3394341	W10299847	Pulley-Motor
62	8538262	279827	Motor-Drve
63	660658		Clamp, Motor Mounting 343481 685441
64	3404162		Clamp, Motor
67	3405245		5/16-18 X 3/4
68	697776	4331106	Screw, No.10-32 X 7/16
69	279318		Terminal Tinned And Brass Panel

