


Whirlpool RTW4240SQ0 02 - CONTROLS AND REAR PANEL PARTS



Whirlpool Residential Whirlpool RTW4240SQ0 Washer Parts Parts Diagram 02 - CONTROLS AND REAR PANEL PARTS

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	3976300	16123		Washer Inlet-Hose Miscellaneous Parts Must be Ordered Separately.
2	9740848			Screw, Mixing Valve Mounting
3	8571377	89503		Hose-Inlet
"	8571378	89503		Hose-Inlet
4	8577378			U-Bend, Drain Hose
5	8568314			Strap, Console
6	8318015			Panel, Rear
7	62747			Pad, Rear Panel
8	8559373	W10096921		Drain Hose Assembly
9	8546681			Timer, Control
10	3351614			Screw, Gearcase Cover Mounting
11	90767			Screw, 8A X 3/8 HeX Washer Head Tapping
12	8577845	W10339334		Switch-WL

13	3948608		Bracket, Control
14	8578842	285800	Cord-Power
15	3952821	285777	Relief-Str
16	8274437	279960	Endcap
17	8318046		Clip, Capacitor
18	8578340		Valve, Water Inlet W/Bi-Metal
19	8541668		Clamp, Hose
20	62863	3390631	Screw, 10-16 X 3/8
21	301958	596669	Clamp, Manifold
22	8317974	8317926	Hose, Vacuum Break
23	370450	596669	Clamp, Manifold
24	387606	3360977	Break-Vac
25	303294	3367669	Protector, Edge
26	8519200		Support, Rear Panel
27	8541667		Clamp, Hose
28	8055003		Clip, Harness And Pressure Switch
29	357021	8572717	Capacitor, Motor Start
30	3363366	616099	Clamp
31	8317496	285655	Clamp, Hose
32	3951449	285871	Hose
33	3400073		Screw, Ground
34	8578337		Switch, Water Temperature
35	3400818		Screw, Timer Mounting
36	8541669		Bucket, Drain Hose
37	8541658		Bucket, Drain Hose
38	3957004		Panel, Console
39	8538949		Knob, Timer
40	8538955		Dial, Timer
41	8538957		Knob, Control
42	8536939		Clip, Knob
43	388326		Screw, 8-18 X 1.25
44	8274434	279960	Endcap
45	3347868	W10339879	Tie, Cable
46	8539874		Shield, Suds
47	3958095		Harness, Wiring

