


Whirlpool RTW4340SQ0 02 - CONTROLS AND REAR PANEL PARTS



8181307

3

Whirlpool Residential Whirlpool RTW4340SQ0 Washer Parts Parts Diagram 02 - CONTROLS AND REAR PANEL PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	3976300	16123		Washer Inlet-Hose Miscellaneous Parts Must be Ordered Separately.
2	9740848			Screw, Mixing Valve Mounting
3	8571377	89503		Hose-Inlet
"	8571378	89503		Hose-Inlet
4	8577378			U-Bend, Drain Hose
5	8568314			Strap, Console
6	8318015			Panel, Rear
7	62747			Pad, Rear Panel
8	8559373	W10096921		Drain Hose Assembly
9	8572976			Timer, Control
10	3351614			Screw, Gearcase Cover Mounting
11	90767			Screw, 8A X 3/8 HeX Washer Head Tapping
12	8577844	W10339251		Switch-WL

13	3948608		Bracket, Control
14	3956162	285800	Cord-Power
15	3952821	285777	Relief-Str
16	8274437	279960	Endcap
17	8318046		Clip, Capacitor
18	8578340		Valve, Water Inlet W/Bi-Metal
19	8541668		Clamp, Hose
20	62863	3390631	Screw, 10-16 X 3/8
21	301958	596669	Clamp, Manifold
22	8317974	8317926	Hose, Vacuum Break
23	370450	596669	Clamp, Manifold
24	387606	3360977	Break-Vac
25	303294	3367669	Protector, Edge
26	8519200		Support, Rear Panel
27	8541667		Clamp, Hose
28	8055003		Clip, Harness And Pressure Switch
29	8572717		Capacitor, Motor Start
30	3363366	616099	Clamp
31	8317496	285655	Clamp, Hose
32	3951449	285871	Hose
33	3400073		Screw, Ground
35	8578337		Switch, Water Temperature
36	3400818		Screw, Timer Mounting
37	8541669		Bucket, Drain Hose
38	8541658		Bucket, Drain Hose
39	3956990		Panel, Console
44	8538949		Knob, Timer
45	8538955		Dial, Timer
46	8538957		Knob, Control
47	8536939		Clip, Knob
49	388326		Screw, 8-18 X 1.25
51	8274434	279960	Endcap
52	8317975		Restraint, Harness
53	3347868	W10339879	Tie, Cable
54	8539874		Shield, Suds
55	3958082		Harness, Wiring

