


Whirlpool TAWB600JQ1 02 - CONTROL AND REAR PANEL PARTS



8180120

3

Whirlpool Residential Whirlpool TAWB600JQ1 Washer Parts Parts Diagram 02 - CONTROL AND REAR PANEL PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	3976300	16123		Washer Inlet-Hose Miscellaneous Parts Must be Ordered Separately.
2	661612	W10168256		Switch, Water Temperature
3	3949374	89503		Hose-Inlet
"	3949375	89503		Hose-Inlet
4	3357027			Nozzle, Hose Drain
5	8318255	8568314		Strap, Console
6	3357976			Panel, Rear
7	62747			Pad, Rear Panel
8	3951609	285664		Hose
"	661577	285666		Hose
"	3357090	285702		Hose
9	3951154			Timer, Control
10	3351614			Screw, Gearcase Cover Mounting
11	90767			Screw, 8A X 3/8 HeX Washer Head Tapping

12	3366848	W10339229	Switch-WL
13	3948814		Bracket, Control
14	661661	285800	Cord-Power
15	3952821	285777	Relief-Str
16	8274437	279960	Endcap
17	661606	8572717	Capacitor, Motor Start
18	3955673	285805	Valve-Inlet
19	9740848		Screw, Mixing Valve Mounting
20	8318201	8318046	Clip, Capacitor
21	370451	596669	Clamp, Manifold
22	62662	3357328	Hose, Vacuum Break
23	371503	596669	Clamp, Manifold
24	3347034		Break, Vacuum
25	303294	3367669	Protector, Edge
26	8317940	W10358149	Drain Hose Assembly
27	3366912	356138	Clamp, Hose
28	3400073		Screw, Ground
30	3363366	616099	Clamp
31	8317496	285655	Clamp, Hose
32	3951449	285871	Hose
33	3976395		Restraint, Hose
36	3400818		Screw, Timer Mounting
37	3950759	3957796	Knob, Control
39	3955507		Panel, Console
44	3951026	3957821	Knob, Timer
45	3950762	3957841	Dial, Timer
49	388326		Screw, 8-18 X 1.25
50	62863	3390631	Screw, 10-16 X 3/8
51	8274434	279960	Endcap
55	3347812	8528351	Clip
56	3366913	3357331	Clamp, Drain
57	3956517		Harness, Wiring

