


Whirlpool TAWS850PQ0 02 - CONTROLS AND REAR PANEL PARTS



8180399

3

Whirlpool Residential Whirlpool TAWS850PQ0 Washer Parts Parts Diagram 02 - CONTROLS AND REAR PANEL PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	3976300	16123		Washer Inlet-Hose Miscellaneous Parts Must be Ordered Separately.
2	9740848			Screw, Mixing Valve Mounting
3	3949374	89503		Hose-Inlet
"	3949375	89503		Hose-Inlet
4	3357027			Nozzle, Hose Drain
5	8318255	8568314		Strap, Console
6	3357978			Panel, Rear
7	62747			Pad, Rear Panel
8	3951609	285664		Hose
"	661577	285666		Hose
"	3357090	285702		Hose
9	8541270			Timer, Control
10	8055003			Clip, Harness And Pressure Switch
11	3351614			Screw, Gearcase Cover

11	3591014		Mounting
12	3366846	W10335056	Switch-WL
13	3948608		Bracket, Control
14	661661	285800	Cord-Power
15	3952821	285777	Relief-Str
16	8274437	279960	Endcap
17	3400073		Screw, Ground
18	3952164	285805	Valve-Inlet
19	3976395		Restraint, Hose
20	8318046		Clip, Capacitor
21	301958	596669	Clamp, Manifold
22	8541607	3357328	Hose, Vacuum Break
23	370450	596669	Clamp, Manifold
24	387606	3360977	Break-Vac
25	303294	3367669	Protector, Edge
26	8317940	W10358149	Drain Hose Assembly
27	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
28	3366912	356138	Clamp, Hose
29	661606	8572717	Capacitor, Motor Start
30	3363366	616099	Clamp
31	8317496	285655	Clamp, Hose
32	3951449	285871	Hose
33	3949180	W10168257	Switch, Rotary
34	8317975		Restraint, Harness
35	661614		Switch, Water Temperature
36	3400818		Screw, Timer Mounting
38	694419		Mini-Buzzer
39	3956980		Panel, Console
44	3956906		Knob, Timer
45	8557458	Not Available	Dial, Timer
47	8557460		Knob, Control
49	388326		Screw, 8-18 X 1.25
50	62863	3390631	Screw, 10-16 X 3/8
51	8274434	279960	Endcap
55	8536939		Clip, Knob
56	3366913	3357331	Clamp, Drain
59	8539874		Shield, Suds
60	3957026		Harness, Wiring

the laundry company[®]