


Whirlpool TEDX340RW2 02 - CABINET PARTS



8180980

3

Whirlpool [Residential Whirlpool TEDX340RW2 Dryer Parts](#) Parts Diagram 02 - CABINET PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	8541400			Bracket, Cabinet
2	3393008	308685		Side Trim)
3	694091			Trim, Side Right Hand
4	343641	681414		Screw, 10AB X 1/2
5	3396795			Cover, Terminal Block
7	3396807	280040		Panel-Rear
8	342055	488627		Screw
10	3406102			Door Switch Assembly
11	697773	3395530		Screw
13	693995			Screw, Hex Head
16	3392100	49621		Feet-Leveling
18	8530603	8533643		Cabinet
19	98234			Clip, U-Bend
20	690363	18776		Lock, Front Top
21	693197	280062		Panel
23	685203	279220		Clip

24	3389441		Door Catch Assembly
28	348023		Hinge And Pin Assembly
29	3394083		Clip, Front Panel
33	696144	279570	Latch
35	695656	280077	Door
36	348205		Door, Front
37	686711		Handle, Door
38	8066123	279264	Air Channel Box
40	279393		Terminal Block Screw Kit
41	3397659		Block, Terminal
51	238088	8066217	Hinge, Top
53	691366		Idler And Pulley Assembly
56	8066065	341241	Belt
57	348780		Base, Motor
58	3400500		Bolt, 3405245 5/16-18 X 3/4
59	3394341	W10299847	Pulley-Motor
62	8066206	279827	Motor-Drve
63	660658		Clamp, Motor Mounting 343481 685441
64	3404162		Clamp, Motor
67	3390734		Seal, Door
68	697776	4331106	Screw, No.10-32 X 7/16
69	279318		Terminal Tinned And Brass Panel

Howes
the laundry company®

Howes
the laundry company®