


Whirlpool WED5200TQ0 01 - TOP AND CONSOLE PARTS



TOP AND CONSOLE PARTS

For Model: WED5200TQ0
(Designer White)

29" ELECTRIC DRYER



2-07 Litho in U.S.A. (LT)

1

Part No. W10131185 Rev.A.

Whirlpool Residential Whirlpool WED5200TQ0 Dryer Parts Parts Diagram 01 - TOP AND CONSOLE PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	8578183		Not Available	Use And Care Guide
"	W10042960		Not Available	Sheet, Cycle Feature
"	8577188		Not Available	Instructions, Installation
"	8576793		Not Available	Wiring Diagram
"	BLANK		Not Available	Following May Be Purchased DO-IT-YOURSELF REPAIR MANUALS
"	677818		Not Available	Manual, Do-It- Yourself Repair (Dryer)
2	693995			Screw, Hex Head
3	8533971	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
4	8271365	279962		Endcap
5	3936144			Do-It-Yourself Repair Manuals
6	388326			Screw, 8-18 X 1.25
7	8533951	3400859		Screw, Grounding
8	8271359	279962		Endcap
9	8274261			Do-It-Yourself Repair Manuals

10	8557861		Screen, Lint
11	8536939		Clip, Knob
13	688983	487240	Screw, For Mtg. Service Capacitor
14	94614		Terminal
15	3395683		Receptacle, Multi-Terminal
16	8557930	8563985	Top
18	3394427		Clip-Harness
21	8299778		Timer, 60 Hz
22	357213		Nut, Push-In
23	8576500	W10450292	Harness, Wiring
24	3977456		Switch, Push-To-Start
25	8566061		Timer Knob Assembly
26	8544895		Bracket, Control
27	8578844		Panel, Control
28	8566065		Knob, Push-To-Start

