


Whirlpool WED5700VW1 02 - CABINET PARTS



W10252086

3

Whirlpool [Residential Whirlpool WED5700VW1 Dryer Parts](#) Parts Diagram 02 - CABINET PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
2	343641	681414		Screw, 10AB X 1/2
3	693995			Screw, Hex Head
4	8541400			Bracket, Cabinet
5	3396795			Cover, Terminal Block
6	342043	486146		Screw
7	3396805	280043		Panel-Rear
8	W10194250	279827		Motor-Drve
9	3393008	308685		Side Trim)
10	3406107			Door Switch Assembly
11	697773	3395530		Screw
12	3390731			Seal, Door
13	3357011	308685		Side Trim)
14	W10041960			Spring, Door
15	3394083			Clip, Front Panel
16	3392100	49621		Feet-Leveling
"	279810			Foot-Optional

17	279318		Terminal Tinned And Brass Panel
18	8530603	8533643	Cabinet
"	W10208297		Cabinet (Includes Illus. 4) (Red)
19	98234		Clip, U-Bend
20	690363	18776	Lock, Front Top
21	695620	279443	Panel
"	W10208301		Panel, Front
22	3404162		Clamp, Motor
23	685203	279220	Clip
24	3389441		Door Catch Assembly
25	W10121316		Plug, Multivent
26	337189		Clip, Hinge
27	694091		Trim, Side Right Hand
28	8066056		Hinge, Door
"	8066057		Hinge, Door
29	696144	279570	Latch
30	695737		Door, Rear
31	3393549		Door, Front
"	W10205714		Door, Front
32	W10095180		Handle, Door
"	W10205821		Handle, Door
33	3406129		Seal And Bearing Assembly
34	279393		Terminal Block Screw Kit
35	697776	4331106	Screw, No.10-32 X 7/16
36	3397659		Block, Terminal
37	8066217		Hinge, Top
38	691366		Idler And Pulley Assembly
39	W10131364	341241	Belt
40	348780		Base, Motor
41	3400500		Bolt, 3405245 5/16-18 X 3/4
42	8066184		Pulley, Motor

