


Whirlpool WED5700XL0 01 - TOP AND CONSOLE PARTS



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

4-11 Printed in U.S.A. (LT) (paw)

1

Part No. W10334899 Rev. B

Whirlpool Residential Whirlpool WED5700XL0 Dryer Parts Parts Diagram 01 - TOP AND CONSOLE PARTS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10096988		Not Available	INSTALLATION INSTRUCTIONS
"	W10097053		Not Available	GUIDE, USE & CARE
"	W10096966		Not Available	TECH SHEET
2	W10269611			Console Assembly
"	W10293251			Console Assembly
3	W10251392			Knob Assembly
4	W10269626			User Interface Assembly
5	W10325119			Spacer, Knob
6	W10274524			Tensioner, Facia
7	W10298336			8-18 Nch, U-Type NUT
8	W10280079			Seal, Console
9	W10096969			Panel, Rear Console
10	693995			Screw, Hex Head
11	W10279552			Plug-Upper Rear Panel
12	W10260246			Top
"	W10268729			Top

13	3390647	488729	Screw
14	8312709		Clip-Console
15	W10286180	W10119283	Cover, Terminal Block
16	W10271580		Bracket, Motor Control
17	3390814	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
18	8536939		Clip, Knob
19	W10287252		Harness, Electric
20	W10219342		Screw, Baffle Mounting
21	W10214008		Control, Electronic
22	W10123956		Dampening Panel
23	W10285494		Cable, User Interface
24	W10323092		Seal, User Interface

the laundry company[®]

the laundry company[®]

the laundry company[®]