



**NON – ILLUSTRATED  
PARTS**

Includes

Optional Parts

Parts Not Included

Miscellaneous Parts



[Whirlpool Residential Whirlpool WED5700XL0 Dryer Parts Parts Diagram 05 - OPTIONAL PARTS \(NOT INCLUDED\)](#)  
[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
NI	80047			PAINT, BULK (1 QT.) (KIT, DRYER REPAIR)
"	<a href="#">8522199</a>			Accessory Parts
"	<a href="#">8212450A</a>			Dryer Rack
"	<a href="#">72017</a>			Paint, Touch-Up
"	<a href="#">W10268217</a>			Paint, Touch-Up
"	<a href="#">350930</a>			Paint, Pressurized Spray B
"	<a href="#">350938</a>			Paint, Pressurized Spray B
"	<a href="#">799344</a>			Paint, Touch-Up )
"	<a href="#">PT220L</a>			Accessory Parts
"	<a href="#">PT400L</a>			Accessory Parts
"	<a href="#">PT600L</a>			Accessory Parts