


# Whirlpool WED5790ST0 02 - TOP AND CONSOLE PARTS

## TOP AND CONSOLE PARTS

For Models: WED5790SQ0, WED5790ST0  
(Designer White) (Biscuit)



W10113143

3

Whirlpool [Residential Whirlpool WED5790ST0 Dryer Parts](#) Parts Diagram 02 - TOP AND CONSOLE PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">8274261</a>			Do-It-Yourself Repair Manuals
2	<a href="#">3401684</a>			Jumper, Wire
3	<a href="#">693995</a>			Screw, Hex Head
4	8271365	<a href="#">279962</a>		Endcap
"	8271368	<a href="#">279965</a>		Endcap
5	<a href="#">3405156</a>			Switch, Rotary
6	<a href="#">388326</a>			Screw, 8-18 X 1.25
7	<a href="#">694419</a>			Mini-Buzzer
8	8271359	<a href="#">279962</a>		Endcap
"	8271362	<a href="#">279965</a>		Endcap
9	<a href="#">3399639</a>			Switch, Rotary Temperature
10	<a href="#">8557857</a>			Screen, Lint
"	<a href="#">8557858</a>			Screen, Lint
11	<a href="#">8536939</a>			Clip, Knob
12	8533971	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
				Screw, For Mtn. Service

13	688983	<a href="#">487240</a>	Screw, For Mtg. Service Capacitor
14	8533951	<a href="#">3400859</a>	Screw, Grounding
15	<a href="#">3395683</a>		Receptacle, Multi-Terminal
16	8557930	<a href="#">8563985</a>	Top
"	8557931	<a href="#">8563986</a>	Top
17	<a href="#">8565944</a>		Knob, Control
"	<a href="#">8565947</a>		Knob, Control
18	<a href="#">3394427</a>		Clip-Harness
19	<a href="#">8566073</a>		Knob, Push-To-Start
"	<a href="#">8566076</a>		Knob, Push-To-Start
20	<a href="#">3401144</a>		Connector
21	<a href="#">3979618</a>		Timer Assembly
22	<a href="#">3397695</a>		Wire, Jumper
23	3396029	<a href="#">8539893</a>	Wire, Jumper
30	<a href="#">357213</a>		Nut, Push-In
31	8299873	<a href="#">8576503</a>	Harness, Wiring
33	<a href="#">3397269</a>		Connector, Timer
34	<a href="#">3347243</a>		Block, Disconnect
35	<a href="#">94614</a>		Terminal
36	<a href="#">3398095</a>		Switch, Push-To-Start
37	<a href="#">8566061</a>		Timer Knob Assembly
"	<a href="#">8566064</a>		Timer Knob Assembly
38	<a href="#">3936144</a>		Do-It-Yourself Repair Manuals
39	<a href="#">8544895</a>		Bracket, Control
40	<a href="#">8578856</a>		Panel, Control
"	<a href="#">8578857</a>		Panel, Control

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>