


Whirlpool WED6200SW1 03 - BULKHEAD PARTS, OPTIONAL PARTS
(NOT INCLUDED)



W10121109

5

Whirlpool [Residential Whirlpool WED6200SW1 Dryer Parts](#) Parts Diagram 03 - BULKHEAD PARTS, OPTIONAL PARTS
(NOT INCLUDED)

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	8544805			Lint Chute Assembly
2	487909	488729		Screw
3	3387459	W10080960		Washer, Support
4	347139			Seal, Lint Chute
5	90767			Screw, 8A X 3/8 HeX Washer Head Tapping
6	8573836			Shield, Exhaust
7	3392519			Thermal Limiter
8	8577891			Thermostat, Hi-Limit
9	3977393	279816		Cutoff-Tml
10	694089			Wheel, Blower
11	8577230			Housing, Blower
12	8546149			Clip-Heater Box
13	343641	681414		Screw, 10AB X 1/2
14	8544801			Box, Heater

15	W10053480		Bracket, Lint Chute
16	3977373		Bracket, Drum Light
17	3403585	279838	Element
18	8544813		Seal, Lint Chute
19	279457		Wire Kit, Terminal
20	489463		Screw, 8-18 X 1/16
21	3390631		Screw, 10-16 X 3/8
22	3406124	22002263	Lamp
23	8558890		Bulkhead, Front
24	3402841	8532165	Lens, Drum Light
25	690997		Washer, Thrust
26	8575325	W10359272	Shaft, Roller Drum Threads
27	8575324	W10359271	Shaft, Drum Roller Threads
28	8536973	W10314173	Support
29	W10001120	W10080190	Nut, 3/8-16
30	8576468		Assembly, Sensor
31	8557242		Bulkhead, Rear
32	3934666	W10080210	Nut, 3/8 X 16
35	8557277	280140	Seal
36	W10109200		Screw, Baffle Mounting
37	8557270	8557272	Drum, Assembly
38	8565688		Baffle, Drum
39	3403634	W10136369	Socket, Drum Light Assembly
40	8577274		Thermostat 295F
41	8544810		Collar, Lint Chute
	BLANK	Not Available	ACCESSORY PARTS
"	279948	4392065	Kit, Dryer Repair
"	W10071550	W10071550A	Dryer Rack
"	8522199		Accessory Parts
"	72017		Paint, Touch-Up
"	350930		Paint, Pressurized Spray B
"	350938		Paint, Pressurized Spray B
"	799344		Paint, Touch-Up)

