


# Whirlpool WED6400SW1 01 - CABINET PARTS



## CABINET PARTS

For Model: WED6400SW1, WED6400SB1, WED6400SG1  
(White/Grey) (Black) (Biscuit/Gold)

29" ELECTRIC DRYER



2-07 Litho in U.S.A. (LT.)

1

Part No. W10118947 Rev. A

Whirlpool [Residential Whirlpool WED6400SW1 Dryer Parts](#) Parts Diagram 01 - CABINET PARTS  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10054150		Not Available	Tech Sheet
"	W10054090		Not Available	Guide, Quick Start
"	W10054070		Not Available	Use & Care Guide
"	BLANK		Not Available	Following May Be Purchased DO-IT-YOURSELF REPAIR MANUALS
"	LIT677818	<a href="#">677818L</a>		Diy
2	343641	<a href="#">681414</a>		Screw, 10AB X 1/2
3	<a href="#">693995</a>			Screw, Hex Head
4	<a href="#">W10007520</a>			Clip, Ground
5	<a href="#">W10110241</a>			Cover, Terminal Block
6	<a href="#">8576625</a>			Lock, Front Top
7	8558830		Not Available	Panel, Rear
8	<a href="#">3404413</a>			Plug, Hinge Hole
"	<a href="#">3404416</a>			Plug-Hole
"	<a href="#">3404415</a>			Plug, Hinge Hole
9	<a href="#">8568303</a>			Locator, Snap Down

10	3978977	<a href="#">W10201787</a>	Switch-Dor
11	<a href="#">3389420</a>		Retainer-Idler 1/4-20 X 1/16
12	8575027	<a href="#">W10239307</a>	Seal-Door
13	342055	<a href="#">488627</a>	Screw
14	<a href="#">8578538</a>		Restrainer, Belt
15	<a href="#">3394083</a>		Clip, Front Panel
16	3392100	<a href="#">49621</a>	Feet-Leveling
"	<a href="#">279810</a>		Foot-Optional
17	<a href="#">279318</a>		Terminal Tinned And Brass Panel
18	8557569	<a href="#">8563672</a>	Cabinet
"	W10045390	<a href="#">W10110409</a>	Cabinet
"	8572115	<a href="#">8563673</a>	Cabinet
19	<a href="#">W10076060</a>		Gasket, Inner Door
20	<a href="#">3387374</a>		Spring, Idler
21	8565029	<a href="#">W10328862</a>	Panel
"	8565032	<a href="#">W10174286</a>	Panel
"	8565031	<a href="#">W10174284</a>	Panel
22	<a href="#">8566208</a>		Assembly, Switch
23	<a href="#">660658</a>		Clamp, Motor Mounting 343481 685441
24	8572982	<a href="#">W10111905</a>	Assembly, Door Catch
25	<a href="#">8578560</a>		Hole, Plug
26	3393008	<a href="#">308685</a>	Side Trim )
27	<a href="#">3390631</a>		Screw, 10-16 X 3/8
28	<a href="#">8565018</a>		Assembly, Hinge And Pin
"	<a href="#">W10050090</a>		Assembly, Hinge And Pin
"	<a href="#">W10050050</a>		Assembly, Hinge And Pin
29	<a href="#">8564011</a>		Bracket-Switch
30	<a href="#">8539897</a>		Jumper,
31	8533974	<a href="#">4331106</a>	Screw, No.10-32 X 7/16
32	<a href="#">8575030</a>		Window, Outer Door
"	<a href="#">8575049</a>		Window, Outer Door
"	<a href="#">8575050</a>		Window, Outer Door
33	8572983	<a href="#">W10295405</a>	Strike
34	<a href="#">308499</a>		Nut-1/4 Hf Self-Thread
35	<a href="#">8565037</a>		Door Inner
"	8575052	<a href="#">8565037</a>	Door Inner
36	<a href="#">W10116925</a>		Door, Outer
"	<a href="#">W10116927</a>		Door, Outer
"	<a href="#">W10116926</a>		Door, Outer
37	W10111246	<a href="#">W10119087</a>	Handle
"	<a href="#">W10111248</a>		Handle, Door
"	<a href="#">W10111247</a>		Door Handle
38	<a href="#">W10044490</a>		Seal, Front Panel
39	<a href="#">279393</a>		Terminal Block Screw Kit
40	342055	<a href="#">488627</a>	Screw
41	<a href="#">3397659</a>		Block, Terminal
42	<a href="#">8547174</a>		Idler And Pulley Assembly
43	<a href="#">8547168</a>		Belt, Drive
44	<a href="#">8547166</a>		Base, Motor
45	<a href="#">W10002600</a>		Screw, 6-20 X 1 1/4
46	<a href="#">8578565</a>		Pulley, 60 Hz

47	8566152	<a href="#">W10463866</a>	Motor-Drive
48	238088	<a href="#">8066217</a>	Hinge, Top
49	<a href="#">8565015</a>		Glass, Inner Door
50	<a href="#">W10100830</a>		Screw, 10-16 X 3/64
51	<a href="#">18849</a>		Pad, Top Hinge

