


Whirlpool WED6600WL0 01 - TOP AND CONSOLE PARTS



TOP AND CONSOLE PARTS

For Model: WED6600WL0
(Lunar Silver)

29" ELECTRIC DRYER



3-09 Litho in U.S.A. (LT.) (psw)

1

Part No. W10260033 Rev. A

Whirlpool Residential Whirlpool WED6600WL0 Dryer Parts Parts Diagram 01 - TOP AND CONSOLE PARTS

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10156037		Not Available	Tech Sheet
"	W10164159		Not Available	Guide, Use & Care
"	W10150650		Not Available	Guide, Quick Start
"	W10139322		Not Available	TIP SHEET DRYER STEAM
"	W10134980		Not Available	Installation, Diagonostic Guide
"	W10166435		Not Available	Performance Tip Sheet
2	8558863			Bracket, Console
3	237446	487596		Washer
4	W10051165			Assembly, User Interface
5	W10252836			Panel, Console
6	3196537	3196557		Panel, Manifold
7	8564265			Cover, Rear- User Interface
8	W10003770			Screw, 6-19 X 1/2
9	W10251181			Knob, Assembly
10	8572270			Assembly, Lint Screen
11	W10249709			Cover, Lint Screen

12	W10044470		Hinge, RH
"	W10044480		Hinge, L.H.
13	W10131402		Screw, 8-18 X 1.370
14	W10183819		Seal-Foam Console
15	3395683		Receptacle, Multi-Terminal
16	W10249705		Top
17	W10111616		Control, Electronic
18	3394427		Clip-Harness
19	8563853		Bracket, Machine Controller
20	337686	Not Available	SCREW, 8-18 X .500
21	W10112673		Screw, Grommet
22	W10141980		Harness Wiring
23	3936144		Do-It-Yourself Repair Manuals
24	94614		Terminal
25	3397269		Connector, Timer

