


Whirlpool WED7990XG0 02 - CABINET PARTS



Whirlpool Residential Whirlpool WED7990XG0 Dryer Parts Parts Diagram 02 - CABINET PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10301602			Screw, M5-0.5 X 10
2	343641	681414		Screw, 10AB X 1/2
3	693995			Screw, Hex Head
4	8538263	279787		Motor-Drive
5	W10286180	W10119283		Cover, Terminal Block
6	8578220			Pulley, Motor
7	W10285822			Panel, Rear
8	W10242878			Bracket, Motor Mounting
9	3387610	661570		Belt
10	W10296342			Door Switch Assembly
11	3389420			Retainer-Idler 1/4-20 X 1/16
12	3388674	W10118756		Idler Bracket
13	3397659			Block, Terminal
14	279393			Terminal Block Screw Kit
15	W10285780			Door Outer Assembly
16	3392100	49621		Feet-Leveling

NI	279810		Foot-Optional
17	279318		Terminal Tinned And Brass Panel
18	W10285809		Panel, Side
19	W10272397	W10329710	Door Catch Assembly
20	3387374		Spring, Idler
21	W10285788		Panel, Front
22	W10246525	W10314253	Switch, Assembly Broken Belt
23	W10121316		Plug, Multivent
24	W10208401		Spring Catch Assembly
25	8565046		(BROKEN BELT BASE, CABINET SWITCH)
26	3393008	308685	Side Trim)
27	W10285792		Door Inner Assembly
28	W10285801		Hinge, Door Assembly
29	W10278915		Strike, Door
30	W10208417		Window Inner Door
31	8533974	4331106	Screw, No.10-32 X 7/16
32	W10285803	Not Available	WINDOW OUTER DOOR
33	W10285793		Door, Inner
34	W10278916		Bezel, Door Switch
35	W10301601		Screw
36	W10208252		Bracket, Glass
37	3393258	3373329D	Screw
38	3388672	279640	Pulley-ldr
39	W10121334		Washer, Thrust
40	690997		Washer, Thrust
41	3357011	308685	Side Trim)

the laundry company[®]

the laundry company[®]