


**Whirlpool WED8300SB2 04 - DOOR PARTS, OPTIONAL PARTS (NOT INCLUDED)**

**DOOR PARTS**  
For Model: WED8300SW2, WED8300SB2  
(White) (Black)



W10176809

7

Whirlpool [Residential Whirlpool WED8300SB2 Dryer Parts](#) Parts Diagram 04 - DOOR PARTS, OPTIONAL PARTS (NOT INCLUDED)

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">8565119</a>			Label, Hinge Hole Cover
2	<a href="#">8578887</a>			Door Hinge Assembly
3	<a href="#">W10044180</a>			Door Intermediate Stationary
4	<a href="#">8534044</a>			Screw, 8-18 X 1/2
5	<a href="#">W10108900</a>			Door Intermediate Stationary
"	<a href="#">W10129704</a>			Door Intermediate Stationary
6	<a href="#">8571836</a>			Door Ring
"	<a href="#">W10129706</a>			Door Ring
7	BLANK		Not Available	Door Seal (Not Serviceable)
8	<a href="#">W10159996</a>			Screw, 10-24 X 25/64
9	<a href="#">8571839</a>			Cover, Hinge
"	<a href="#">W10129722</a>			Cover, Hinge
10	8578933	<a href="#">W10164062</a>		Door Assembly
11	<a href="#">355515</a>			Screw, 8-18 X 11/16
12	3393258	<a href="#">3373329D</a>		Screw

13	8565117	<a href="#">W10286878</a>	Window
14	690081	<a href="#">279570</a>	Latch
15	<a href="#">8579663</a>		Seal, Window
16	<a href="#">8519354</a>		Retainer-Window
17	<a href="#">8534022</a>		Screw, 8-18 X 1/16
18	<a href="#">8519356</a>		Retainer-Window
	<a href="#">72017</a>		Paint, Touch-Up
"	72302	Not Available	PAINT, TOUCH-UP (1/2oz.) (Black)
"	<a href="#">350930</a>		Paint, Pressurized Spray B
"	786020	Not Available	PAINT, PRESSURIZED SPRAY (12 oz.) (Black)
"	<a href="#">350938</a>		Paint, Pressurized Spray B
"	<a href="#">799344</a>		Paint, Touch-Up )
"	786302	Not Available	PAINT, BULK (1 qt.) (Black (Uncut))
"	BLANK	Not Available	ACCESSORY PARTS
"	8529894	<a href="#">346764</a>	Kit, Hold Down
"	<a href="#">8522199</a>		Accessory Parts
"	80047		PAINT, BULK (1 QT.) (KIT, DRYER REPAIR)
"	8563738	<a href="#">W10121663</a>	Dryer Rack

