


Whirlpool WED8410SW1 04 - DOOR PARTS, OPTIONAL PARTS (NOT INCLUDED)

DOOR PARTS
For Model: WED8410SW1
(White/Grey)



W10162786

7

Whirlpool [Residential Whirlpool WED8410SW1 Dryer Parts](#) Parts Diagram 04 - DOOR PARTS, OPTIONAL PARTS (NOT INCLUDED)

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	8565119			Label, Hinge Hole Cover
2	8578887			Door Hinge Assembly
3	W10044180			Door Intermediate Stationary
4	8534044			Screw, 8-18 X 1/2
5	8571840	W10108900		Door Intermediate Stationary
6	8571836			Door Ring
7	3393258	3373329D		Screw
8	W10017850	280203		Screw-Kit
9	8571839			Cover, Hinge
10	8578933	W10164062		Door Assembly
11	355515			Screw, 8-18 X 11/16
12	8519354			Retainer-Window
13	8565117	W10286878		Window
14	690081	279570		Latch
15	8579663			Seal, Window

16	8519356		Retainer-Window
17	8534022		Screw, 8-18 X 1/16
	72017		Paint, Touch-Up
"	350930		Paint, Pressurized Spray B
"	350938		Paint, Pressurized Spray B
"	BLANK	Not Available	ACCESSORY PARTS
"	8529894	346764	Kit, Hold Down
"	8522199		Accessory Parts
"	80047		PAINT, BULK (1 QT.) (KIT, DRYER REPAIR)

