


# Whirlpool WED8600YW0 01 - TOP AND CONSOLE PARTS



## TOP AND CONSOLE PARTS

For Model: WED8600YW0  
(White)

27" ELECTRIC DRYER



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

8-11 Printed in U.S.A. (JLP) (eeb)

1

Part No. W10420730 Rev. A

[Whirlpool Residential Whirlpool WED8600YW0 Dryer Parts](#) Parts Diagram 01 - TOP AND CONSOLE PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">W10398830</a>			Guide, Use And Care
"	W10392124		Not Available	INSTALLATION, INSTRUCTION
"	W10403269		Not Available	TECH SHEET
2	<a href="#">W10403678</a>			Console Assembly
3	<a href="#">W10388674</a>			Assembly, User Interface
4	<a href="#">8564265</a>			Cover, Rear- User Interface
5	<a href="#">W10211335</a>			Knob, Assembly
6	W10368722	<a href="#">W10432259</a>		Control Electronic
7	<a href="#">8572039</a>			Seal, User Interface
8	<a href="#">W10211337</a>			Bracket, Machine Controller
9	<a href="#">W10003770</a>			Screw, 6-19 X 1/2
10	<a href="#">W10112673</a>			Screw, Grommet
11	<a href="#">W10211339</a>			Top
12	<a href="#">W10131402</a>			Screw, 8-18 X 1.370
13	<a href="#">W10185554</a>			Seal, Foam Top
14	<a href="#">W10392403</a>			Harness, Electric

