


Whirlpool WED8800YW0 01 - TOP AND CONSOLE PARTS



TOP AND CONSOLE PARTS

For Models: WED8800YW0, WED8800YC0
(White) (Chrome Shadow)

27" ELECTRIC DRYER



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

8-11 Printed in U.S.A. (JLP) (eeb)

1

Part No. W10441424 Rev. A

[Whirlpool Residential Whirlpool WED8800YW0 Dryer Parts](#) Parts Diagram 01 - TOP AND CONSOLE PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	W10398830			Guide, Use And Care
"	W10392124		Not Available	INSTALLATION, INSTRUCTION
"	W10403269		Not Available	TECH SHEET
2	W10403679			Console Assembly
"	W10391502			Console Assembly
3	W10388673			Assembly, User Interface
4	8564265			Cover, Rear- User Interface
5	W10211335			Knob, Assembly
6	W10368722	W10432259		Control Electronic
7	8572039			Seal, User Interface
8	W10211337			Bracket, Machine Controller
9	W10003770			Screw, 6-19 X 1/2
10	W10112673			Screw, Grommet
11	W10211339			Top
"	W10391495			Plug, Front Panel
12	W10131402			Screw, 8-18 X 1.370

13	W10185554		Seal, Foam Top
14	W10392403		Harness, Electric
15	8558863		Bracket, Console
16	337686	Not Available	SCREW, 8-18 X .500

