



**NON – ILLUSTRATED
PARTS**

the laundry company[®]

Includes

Optional Parts

Parts Not Included

Miscellaneous Parts



Whirlpool [Residential Whirlpool WED9270XL0 Dryer Parts](#) Parts Diagram 05 - OPTIONAL PARTS (NOT INCLUDED)

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
NI	72017			Paint, Touch-Up
"	W10218245			Paint, Touch-Up
"	W10268217			Paint, Touch-Up
"	350930			Paint, Pressurized Spray B
"	350938			Paint, Pressurized Spray B
"	799344			Paint, Touch-Up)
"	8529894	346764		Kit, Hold Down
"	8522199			Accessory Parts
"	80047			PAINT, BULK (1 QT.) (KIT, DRYER REPAIR)
"	PT220L			Accessory Parts
"	PT400L			Accessory Parts
"	PT600L			Accessory Parts
"	W10206708	W10044609A		Hose-Kit
"	89503			Hose-Inlet
"	350027	49583		Hose-Fill
				Washer Inlet-Hose

" W10242307

[16123](#)

Miscellaneous Parts Must be
Ordered Separately.

" W10044604

[49586](#)

Mixer

