


Whirlpool WED9270XR1 04 - DOOR PARTS



Whirlpool [Residential Whirlpool WED9270XR1 Dryer Parts](#) Parts Diagram 04 - DOOR PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10256915			Label, Hinge Hole Cover
2	W10304672	8578887		Door Hinge Assembly
3	N/P		Not Available	SCREEN, DOOR (NOT SERVICEABLE SPERATELY, ORDER ITEM. 19)
4	8534044			Screw, 8-18 X 1/2
5	W10215764			Door, Intermediate Stationary
6	W10215757			Trim, Door Ring Outer
"	W10215824			Door Trim Outer Ring
"	W10215823			Door Trim Outer Ring
7	W10163915			Door Seal
8	W10159996			Screw, 10-24 X 25/64
9	W10215766			Door Trim, Hinge Cover
"	W10215826			Door Trim, Hinge Cover
"	W10215825			Door Trim, Hinge Cover
10	W10198441	W10363674		Door Assembly
11	355515			Screw, 8-18 X 11/16

12	3393258	3373329D	Screw
13	W10286878		Window
14	690081	279570	Latch
15	8579663		Seal, Window
16	8519354		Retainer-Window
17	8534022		Screw, 8-18 X 1/16
18	8519356		Retainer-Window
19	W10215756		Door Assembly Outer
"	W10215831		Door Assembly Outer
"	W10215830		Door Assembly Outer
20	N/P	Not Available	TRIM-DOOR INNER RING (NOT SERVICEABLE SEPERATELY, ORDER ITEM. 19)
21	W10215762	W10431338	Door

