



Whirlpool Residential Whirlpool WED9270XR2 Dryer Parts Parts Diagram 05 - OPTIONAL PARTS (NOT INCLUDED)  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
NI	<a href="#">72017</a>			Paint, Touch-Up
"	<a href="#">W10218245</a>			Paint, Touch-Up
"	<a href="#">W10268217</a>			Paint, Touch-Up
"	<a href="#">350930</a>			Paint, Pressurized Spray B
"	<a href="#">350938</a>			Paint, Pressurized Spray B
"	<a href="#">799344</a>			Paint, Touch-Up )
"	8529894	<a href="#">346764</a>		Kit, Hold Down
"	<a href="#">8522199</a>			Accessory Parts
"	80047			PAINT, BULK (1 QT.) (KIT, DRYER REPAIR)
"	<a href="#">PT220L</a>			Accessory Parts
"	<a href="#">PT400L</a>			Accessory Parts
"	<a href="#">PT600L</a>			Accessory Parts
"	W10362238	<a href="#">W10044609A</a>		Hose-Kit
"	<a href="#">89503</a>			Hose-Inlet
"	<a href="#">W10342767</a>			2' Hose
				Washer Inlet-Hose

" W10242307

[16123](#)

Miscellaneous Parts Must be  
Ordered Separately.

" W10336486

[W10269488](#)

Connector- Hose, Y

