



Whirlpool Residential Whirlpool WED9400SB1 Dryer Parts Parts Diagram 05 - OPTIONAL PARTS (NOT INCLUDED)
 Click on the part number to view part

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|-------------------------|---------------------------|---------------|---|
| NI | 72017 | | | Paint, Touch-Up |
| " | 72302 | | Not Available | PAINT, TOUCH-UP (1/2oz.) (Black) |
| " | 4392899 | | | Paint, Touch-Up |
| " | 8212605 | | | Paint, Pressurized Spray |
| " | 350930 | | | Paint, Pressurized Spray B |
| " | 786020 | | Not Available | PAINT, PRESSURIZED SPRAY (12 oz.) (Black) |
| " | 4392901 | | | Paint, Pressurized Spray |
| " | 350938 | | | Paint, Pressurized Spray B |
| " | 799344 | | | Paint, Touch-Up) |
| " | 4392900 | | | Paint, Bulk) |
| " | 786302 | | Not Available | PAINT, BULK (1 qt.) (Black (Uncut)) |
| " | 8529894 | 346764 | | Kit, Hold Down |
| " | 8541503 | | | Kit, Stack Assembly |
| " | 8579666A | W10466829 | | Blade |

| | | | |
|---|------------------------|---------------------------|---|
| " | 80047 | | PAINT, BULK (1 QT.) (KIT, DRYER REPAIR) |
| " | 8521957 | W10121663 | Dryer Rack |
| " | PT220L | | Accessory Parts |
| " | PT400L | | Accessory Parts |
| " | PT600L | | Accessory Parts |

