


Whirlpool WED9400SW1 04 - DOOR PARTS



Whirlpool [Residential Whirlpool WED9400SW1 Dryer Parts](#) Parts Diagram 04 - DOOR PARTS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10085210			Label-Hinge Hole Cover Front Panel
2	W10139920			Door Hinge Assembly
3	W10159996			Screw, 10-24 X 25/64
4	9742177			Screw, 8-18 X .625
5	W10180119			Cover-Hinge, Stationary Cover Hinge
"	W10181197			Cover Hinge
6	W10139457			Seal-Door Handle, Ring Door
7	8579502			Handle, Door
"	8579503			HANdle-Ring And Pad Assembly
"	8579496			HANdle, Ring And Pad Assembly
8	3400224			Screw, 1/4-20 X 3/8
9	W10180115			Door Assembly
"	W10180116			Door Assembly
"	W10180112			Door Assembly

10	8578229		Door Assembly
11	355515		Screw, 8-18 X 11/16
12	690081	279570	Latch
13	8519356		Retainer-Window
14	8519354		Retainer-Window
15	8579662		Gasket, Window
16	W10048910		Screw-Plug
17	8566254		Glass-Window
19	W10180492		Tear-Drop Trim And Clip Assembly
"	W10180496		Tear-Drop Trim And Clip Assembly
"	W10180497		Tear-Drop Trim And Clip Assembly
"	W10180494		Tear-Drop Trim And Clip Assembly
"	W10180498		Tear-Drop Trim And Clip Assembly
20	W10180120		Shield, Door
21	W10180118		Door, Intermediate
22	W10180117		Door Mask
23	8578155		Door Screen
24	3393258	3373329D	Screw

