


Whirlpool WED9400SW2 02 - CABINET PARTS



Whirlpool Residential Whirlpool WED9400SW2 Dryer Parts Parts Diagram 02 - CABINET PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	8576583	W10119283		Cover, Terminal Block
2	3390814	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
3	8533974	4331106		Screw, No.10-32 X 7/16
4	3397659			Block, Terminal
5	W10246525	W10314253		Switch, Assembly Broken Belt
6	3357011	308685		Side Trim)
7	W10192435			Panel, Side
"	W10192440			Panel, Side
8	3392100	49621		Feet-Leveling
"	279810			Foot-Optional
9	W10121316			Plug, Multivent
10	3387374			Spring, Idler
11	3389420			Retainer-Idler 1/4-20 X 1/16
12	49252			Plug, Multivent
"	8579115	W10117271		Top
13	3388672	279640		Pulley-ldr

14	279318		Terminal Tinned And Brass Panel
15	8519459		Clip, Toe Panel
16	W10180481	280036	Panel-Rear
17	W10123956		Dampening Panel
18	W10121334		Washer, Thrust
19	W10128087	W10318609	Switch, Assembly Door
20	690997		Washer, Thrust
21	8066115	3394331	Plate Cover
22	8529053		Ramp, Door Door Switch
23	343641	681414	Screw, 10AB X 1/2
24	W10192446		Panel, Side
"	W10192451		Panel, Side
25	W10273475		Base, Cabinet
26	62825		Clip-S Type Control Board
27	8538263	279787	Motor-Drve
28	696144	279570	Latch
29	8578220		Pulley, Motor
30	3387610	661570	Belt
31	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
32	W10242878		Bracket, Motor Mounting
33	279393		Terminal Block Screw Kit
34	49026		4" - 90° Elbow
35	W10242904		Harness, Digital Interface
36	8563747		Exhaust Pipe Medium Pipe
37	8563750		Exhaust Pipe
38	8563749		Exhaust Pipe
39	3388674	W10118756	Idler Bracket
40	8563727		Bracket, Control
41	W10174745		Board, Control
42	693995		Screw, Hex Head
43	3390647	488729	Screw
44	3387242		Seal, Front Panel
45	3393008	308685	Side Trim)
46	W10246269		Panel, Toe
"	W10246275		Panel, Toe
47	W10180423		Front Panel
"	W10180429		Front Panel
48	279818	W10470674	Dryer Exhaust Kit

the laundry company[®]