


Whirlpool WED9470WW2 04 - DOOR PARTS

DOOR PARTS

For Model: WED9470WW2

(White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

W10485052

7

Whirlpool [Residential Whirlpool WED9470WW2 Dryer Parts](#) Parts Diagram 04 - DOOR PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	W10085230			Label, Hinge Hole Cover
2	W10139920			Door Hinge Assembly
3	W10159996			Screw, 10-24 X 25/64
4	3400224			Screw, 1/4-20 X 3/8
5	W10180119			Cover-Hinge, Stationary Cover Hinge
NI	N/P		Not Available	(FOLLOWING PARTS NOT INCLUDED)
"	W10181197			Cover Hinge
6	W10139457			Seal-Door Handle, Ring Door
7	W10193522			Door Frame Assembly
8	3393008	308685		Side Trim)
9	W10193530			Door Assembly
10	8578229			Door Assembly
11	355515			Screw, 8-18 X 11/16
12	690081	279570		Latch
13	8519356			Retainer-Window

14	8519354		Retainer-Window
15	8579662		Gasket, Window
16	W10048910		Screw-Plug
17	8566254		Glass-Window
18	W10153281	W10121607	Pad, Door Handle
19	W10246600		Tear-Drop Trim And Clip Assembly
20	W10180120		Shield, Door
21	W10180118		Door, Intermediate
22	W10180117		Door Mask
23	W10171571		Screen, Door
24	3393258	3373329D	Screw
25	8577819		Door Assembly

the laundry company[®]

the laundry company[®]

the laundry company[®]