



Whirlpool [Residential Whirlpool WED9470WW2 Dryer Parts](#) Parts Diagram 05 - OPTIONAL PARTS (NOT INCLUDED)
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
NI	72017			Paint, Touch-Up
"	350930			Paint, Pressurized Spray B
"	350938			Paint, Pressurized Spray B
"	799344			Paint, Touch-Up)
"	8529894	346764		Kit, Hold Down
"	8541503			Kit, Stack Assembly
"	8579666A	W10466829		Blade
"	80047			PAINT, BULK (1 QT.) (KIT, DRYER REPAIR)
"	8521957	W10121663		Dryer Rack
"	W10434773	W10044609A		Hose-Kit
"	W10439654	89503		Hose-Inlet
"	W10439655	W10342767		2' Hose
"	W10242307	16123		Washer Inlet-Hose Miscellaneous Parts Must be Ordered Separately.
"	W10336486	W10269488		Connector- Hose, Y

" [PT220L](#)

Accessory Parts

" [PT400L](#)

Accessory Parts

" [PT600L](#)

Accessory Parts

